

HALO INSTALLATION GUIDE

TABLE OF CONTENTS

1.0 - PRODUCT DESCRIPTION.....	P. 2-3
EXTERRA SHEATHING	P. 2-5
INTERRA SHEATHING	P. 2-6
SUBTERRA SHEATHING	P. 2-7
2.0 - AVAILABLE SIZES	P. 2-8
3.0 - USEFUL TOOLS & MATERIALS	P. 2-9
4.0 - APPLICATIONS	P. 2-10
4.1 - ROOFS & CATHEDRAL CEILINGS	P. 2-11
4.2 - CEILINGS BELOW ATTICS	P. 2-14
4.3.1 EXTERIOR INSULATION	P. 2-16
4.3 - ABOVE-GRADE WALLS	P. 2-16
4.3.2 - INTERIOR INSULATION.....	P. 2-20
4.4.1 - EXTERIOR INSULATION	P. 2-22
4.4 - FOUNDATION WALLS	P. 2-22
4.4.2 - INTERIOR INSULATION	P. 2-24
4.5.1 - ABOVE-SLAB INSULATION.....	P. 2-27
4.5 - BASEMENT SLABS	P. 2-27
4.5.2 - BELOW-SLAB INSULATION	P. 2-29
5.0 - FASTENING HALO	P. 2-31
5.1 - EXTERRA FASTENER INFORMATION	P. 2-32
5.2 - CLADDING OVER EXTERRA	P. 2-34
5.3 - INTERRA FASTENER INFORMATION.....	P. 2-36
5.4 - CLADDING OVER INTERRA.....	P. 2-38
6.0 - MATERIAL PROPERTIES	P. 2-41
6.1 - EXTERRA MATERIAL PROPERTIES.....	P. 2-42

HALO INSTALLATION GUIDE



TABLE OF CONTENTS Cont'd

6.2 - INTERRA MATERIAL PROPERTIES.....	P. 2-43
6.3 - SUBTERRA MATERIAL PROPERTIES.....	P. 2-44
7.0 - EXAMPLE DETAILS	P. 2-45
7.1 - WINDOW/DOOR OPENINGS.....	P. 2-47
7.1.1 - FLANGED WINDOW.....	P. 2-47
7.2 - ABOVE-GRADE DETAILS.....	P. 2-48
7.2.1 - FOUNDATION TRANSITION	P. 2-48
7.2.2 - FLOOR TRANSITION	P. 2-49
7.2.3 - ROOF TRANSITION.....	P. 2-50
7.3 - FOUNDATION WALL DETAILS	P. 2-51
7.3.1 - EXTERIOR/INTERIOR INSULATION	P. 2-51
7.4 - SLAB DETAILS.....	P. 2-52
7.4.1 - ABOVE-/BELOW-SLAB INSULATION	P. 2-52

For more information, or to contact a Halo representative, visit our website at www.buildWithHalo.com and click "Contact Us".

This manual will be updated regularly. Current updates will be available at www.BuildWithHalo.com.